

INTEL CORPORATION

Intel® Embedded University Program

LAB 5.1

Upgrading the Intel® Boot Loader Development Kit II (Intel® BLDK II) onto the InForce Computing* SYS9402 System

This lab provides instructions for upgrading the Intel BLDK II Alpha version on the InForce computing system to the Intel® BLDK II Gold version.

Instructions:


Prerequisites

- 1) *Intel® Embedded University Program LAB 3.1* is complete
- 2) *Intel® Embedded University Program LAB 3.2* is not started on the platform used for this lab.
- 3) A bootable USB flash drive is available for each system under test. The drive should be prepared as detailed in the *USB Flash Drive Preparation* presentation, which is available separately.
- 4) A Host PC system, with a RS-232 serial port, is available with appropriate peripherals and cables. The PC must be running a terminal emulator application, such as PuTTY.
- 5) The terminal emulator should be configured as follows:
 - a. Baud Rate: 115200
 - b. Data Bits: 8
 - c. Stop Bits: 1
 - d. Parity: None
 - e. Flow Control: None


Installation steps:

- 1) If the InForce Computing system is currently powered on, proceed with powering it down
- 2) Detach the SATA data cable (red colored) from the hard drive in the InForce Computing system.
- 3) Insert the USB flash drive into one of the spare USB slots on the InForce Computing system. Do not power the system on yet!
- 4) Power on the host PC system, if it's not already powered, and run the terminal emulator application
- 5) Power on the InForce Computing system
- 6) The system should start powering up, as indicated by
 - a. An Intel logo splash screen on the monitor

- c. The system fan rotating
- 7) If the InForce Computing system does not start to power up, press the power switch on the system. The power switch is on the opposite side of the mainboard to the USB, RS-232, VGA and 12 V DC connectors.




- 8) The first display output should be the Intel logo splash screen. This indicates that the Intel BLDK II (alpha build) bootloader is running
- 9) On the terminal emulator, there should be some debug text from the Intel BLDK II bootloader and a command prompt: *Shell >*



- 10) Type *exit* at the command prompt to allow the bootloader to enumerate all system boot options. A message similar to *Enumerating boot devices ...* should be seen



11) Once enumeration is complete, a *Boot Options:* menu should be seen. Select the *EFI Internal Shell* option to return to the command prompt



12) At the *Shell >* command prompt, type *fs0:* and press *Enter* to enter the USB flash drive file system.

```
COM1 - PuTTY
[ 1 ] - EFI Internal Shell
[ 2 ] - EFI Payload
[ 3 ] - EFI USB Device
-----
Boot from ... 1

Booting from EFI Internal Shell [Fv(30D9ED01-38D2-418A-90D5-C561750BF80F)/FvFile
(C57AD6B7-0515-40A8-9D21-551652854E37)]
EFI Shell version 2.30 [1.0]
Current running mode 1.1.2
Device mapping table
  fs0      :Removable HardDisk - Alias hd24c0b blk0
             PciRoot(0x0)/Pci(0x17,0x0)/Pci(0x0,0x0)/Pci(0x8,0x3)/USB(0x2,0x0)/HD(
1,MBR,0x011A569D,0x3F,0x3D7FC1)
  blk0     :Removable HardDisk - Alias hd24c0b fs0
             PciRoot(0x0)/Pci(0x17,0x0)/Pci(0x0,0x0)/Pci(0x8,0x3)/USB(0x2,0x0)/HD(
1,MBR,0x011A569D,0x3F,0x3D7FC1)
  blk1     :Removable BlockDevice - Alias (null)
             PciRoot(0x0)/Pci(0x17,0x0)/Pci(0x0,0x0)/Pci(0x8,0x3)/USB(0x2,0x0)

Press ESC in 1 seconds to skip startup.nsh, any other key to continue.
Shell> fs0:

fs0:\> █
```

- 13) To start the Intel BLDK II update process, type `spiupdate.efi IFC9400_ROM.BIN` and press *Enter*.

```
Shell> fs0:

fs0:\> spiupdate.efi IFC9400_ROM.BIN
SpiUpdate: 2010-12-01 <for TunnelCreek based platforms>
Updating Block at FFE08000: Writing █
```

- 14) The update process will end with a *Firmware update successful* message. 5 seconds after this point the InForce Computing system will reboot and BLDK II debug text should be visible in the terminal emulator
- Note: The debug text will be slightly different for the Gold version of BLDK II.

```
Shell> fs0:

fs0:\> spiupdate.efi IFC9400_ROM.BIN
SpiUpdate: 2010-12-01 <for TunnelCreek based platforms>
Firmware update successful.   Reset system in 4 seconds ... █
```

- 15) Power off the InForce Computing system, remove the USB flash drive and reattach the SATA data cable to the hard drive.

Legal

This publication is designed to provide accurate and authoritative information in regard to the subject matter covered. It is sold with the understanding that the publisher is not engaged in professional services. If professional advice or other expert assistance is required, the services of a competent professional person should be sought.

Intel Corporation may have patents or pending patent applications, trademarks, copyrights, or other intellectual property rights that relate to the presented subject matter. The furnishing of documents and other materials and information does not provide any license, express or implied, by estoppel or otherwise, to any such patents, trademarks, copyrights, or other intellectual property rights. Intel may make changes to specifications, product descriptions, and plans at any time, without notice. Fictitious names of companies, products, people, characters, and/or data mentioned herein are not intended to represent any real individual, company, product, or event.

Intel products are not intended for use in medical, life saving, life sustaining, critical control or safety systems, or in nuclear facility applications.

Intel and the Intel logo are trademarks or registered trademarks of Intel Corporation or its subsidiaries in the United States and other countries.

* Other names and brands may be claimed as the property of others.

Copyright © 2012 Intel Corporation. All rights reserved

Notices and Disclaimers

ALL INFORMATION PROVIDED WITHIN OR OTHERWISE ASSOCIATED WITH THIS PUBLICATION INCLUDING, INTER ALIA, ALL SOFTWARE CODE, IS PROVIDED "AS IS", AND FOR EDUCATIONAL PURPOSES ONLY. INTEL RETAINS ALL OWNERSHIP INTEREST IN ANY INTELLECTUAL PROPERTY RIGHTS ASSOCIATED WITH THIS INFORMATION AND NO LICENSE, EXPRESS OR IMPLIED, BY ESTOPPEL OR OTHERWISE, TO ANY INTELLECTUAL PROPERTY RIGHT IS GRANTED BY THIS PUBLICATION OR AS A RESULT OF YOUR PURCHASE THEREOF. INTEL ASSUMES NO LIABILITY WHATSOEVER AND INTEL DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY RELATING TO THIS INFORMATION INCLUDING, BY WAY OF EXAMPLE AND NOT LIMITATION, LIABILITY OR WARRANTIES RELATING TO FITNESS FOR A PARTICULAR PURPOSE, MERCHANTABILITY, OR THE INFRINGEMENT OF ANY INTELLECTUAL PROPERTY RIGHT ANYWHERE IN THE WORLD.

THIS SOFTWARE IS PROVIDED BY THE AUTHOR "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL THE AUTHOR BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.