



#RSMRST_N is hard reset to indicate the rtcwell is valid
 #DSW_PWROK is a hard reset to indicate the dswwell is valid
 #RTESTB_N is a hard reset to indicate the rtcwell is valid
 #PCH_PWROK is a hard reset to indicate the corewell is valid
 #SYS_PWROK is a hard reset to indicate the system has been powered up
 #SRTCRST_N is a hard strap to enable bscan